






**whittet-higgins company**

## BEARHUG - BHM SERIES - HIGH STRENGTH



PART NUMBER	THREAD	MAX OUTSIDE DIAMETER (INCHES)	MAX FACE DIAMETER (INCHES)	MAX WIDTH (INCHES)	THEORETICAL AXIAL LOAD (LBS)	CAD MODEL	PART PRINT
BHM-00	0.391-32	0.750	0.625	0.281	4300	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-01	0.469-32	0.875	0.719	0.375	9600	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-02	0.586-32	1.000	0.813	0.376	11900	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-03	0.664-32	1.125	0.938	0.406	15500	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-04	0.781-32	1.375	1.125	0.406	18100	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-05	0.969-32	1.563	1.281	0.469	28600	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-06	1.173-18	1.750	1.500	0.469	28200	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-07	1.376-18	2.063	1.813	0.500	37500	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-08	1.563-18	2.500	2.000	0.500	42700	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-09	1.767-18	2.531	2.281	0.500	47900	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-10	1.967-18	2.688	2.438	0.563	66100	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-11	2.157-18	2.969	2.656	0.563	71900	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-12	2.360-18	3.156	2.844	0.594	86200	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-13	2.548-18	3.375	3.063	0.625	101100	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-14	2.751-18	3.625	3.313	0.625	109200	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-15	2.933-12	3.875	3.563	0.656	101800	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-16	3.137-12	4.156	3.844	0.656	108400	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-17	3.340-12	4.406	4.031	0.719	137600	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-18	3.527-12	4.656	4.281	0.781	166100	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-19	3.730-12	4.938	4.563	0.813	188100	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-20	3.918-12	5.188	4.813	0.844	210200	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-21	4.122-12	5.438	5.000	0.875	185600	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-22	4.325-12	5.719	5.281	0.938	231400	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-24	4.716-12	6.125	5.688	0.938	260700	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-26	5.106-12	6.750	6.188	1.000	317200	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-28	5.497-12	7.094	6.531	1.063	379700	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-30	5.888-12	7.688	7.063	1.125	447000	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-32	6.284-8	8.063	7.438	1.188	474500	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-34	6.659-8	8.656	8.031	1.219	526400	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-36	7.066-8	9.063	8.375	1.250	584300	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-38	7.472-8	9.469	8.781	1.281	644200	<a href="#">STEP</a>	<a href="#">PDF</a>
BHM-40	7.847-8	9.844	9.156	1.313	694500	<a href="#">STEP</a>	<a href="#">PDF</a>

FOR ADDITIONAL ENGINEERING SUPPORT: (401) 728-0700